# ESD

Electrostatic Discharge Measurement & Control Instruments Catalog



An Advanced Energy Company

## **Trek ESD Measurement & Control Instruments - Table of Contents**

	AC Feedback Electrostatic Voltmeters	Model 520-1, Model 876 p.1
	AC Feedback Electrostatic Voltmeters	Model 523-1, Model 884 p.1
	DC Feedback Electrostatic Voltmeter / USB	Model 541A-1p.2
	AC Feedback Electrostatic Voltmeter / USB	Model 542A-1p.2
	Application Software	Model 541A, 542Ap.3
	Hand-Held Contacting Electrostatic Voltmeter	Model 821HHp.3
	Charged Plate Monitor	Model 156Ap.4
	Charged Plate Monitor	Model 157p.4
	Charged Plate Monitor	Model 158Ap.5
	ESD Audit Kit	Model 511/1501p.6
<u> </u>	Electrostatic Field Meter	Model 511p.6
	Surface Resistance Meter	Model 1501p.6
	Surface Resistance / Volume Resistance Meter	Model 152-1p.7
	High Sensitivity ESD Event Detector	Model 901HSp.7
	Nozzle Ionizer	Model 950p.8
	Electrostatic Voltmeters – Measurement Distar	nce & Measurement Area p.10
	Theory of Operation – DC Feedback Electrostatic Voltmeter	
	Theory of Operation – AC Feedback Electrostatic Voltmeter	
	Additional Information – Sales & Service	Back Cover

# Model 520-1, Model 876 AC Feedback Electrostatic Voltmeters

### **Features**

- · Non-contacting voltage measurement
- · No need to maintain fixed spacing; accurate at a wide range of spacings
- Portable (battery operated)
- Good for difficult-to-reach locations (Model 876 has probe-on-cable design)
- Drift-free operation in ionized environments
- Low cost

### **Applications**

Static charge measurement for LCD, semiconductor devices, MR heads. Monitor electrostatic levels in IC production processes. Surface potential measurement of silicon wafers, films and papers. Materials testing. Standard static charge measurements.

### **Specifications**

<del>-</del>	
Measurement Range	0 to ±2kV
Voltage Display	0 to ±1999V
Voltage Resolution	1V
	Range of 5 to 25mm
Accuracy	±5% (Full Scale)
Speed of Response	400ms
Operating Conditions	
Temperature	15 to 35°C
Relative Humidity	to 85%RH, noncondensing
Power Supply	9V alkaline battery (1)
	.1cm H x 14.6cm L (without cable sensor)185g



Model 520-2 (with analog output function)

Output Ratio	1/1000 of the measured voltage
Speed of Response	25ms
Output Terminal	1.3mm jack



# Model 523-1, Model 884 AC Feedback Electrostatic Voltmeters

### **Features**

- Non-contacting voltage measurement
- No need to maintain fixed spacing; accurate at a wide range of spacings
- Portable (battery operated)
- Good for difficult-to-reach locations (Model 884 has probe-on-cable design)
- · Drift-free operation in ionized environments
- · Low cost

### **Applications**

Static charge measurement for LCD, semiconductor devices. Monitor electrostatic levels in IC production processes. Surface potential measurement of silicon wafers, films and papers. Materials testing. Standard static charge measurements.

### **Specifications**

Measurement Range	0 to ±20kV
Voltage Display	0 to ±19.99kV
Voltage Resolution	10V
Probe-to-Surface Separation	Range of 30 to 60mm
Accuracy	±5% (Full Scale)
Speed of Response	
Operating Conditions	
Temperature	15 to 35°C
Relative Humidity	



Power Supply	9V alkaline battery (1)
Dimensions	5.9cm W x 3.1cm H x 14.6cm L (without cable sensor)
Weight	200g



# Model 541A-1 DC Feedback Electrostatic Voltmeter - USB Supported

### **Features**

- USB or RS-232 serial port enables computer-based control & monitoring
- · Visual and audible alarms
- LCD screen displays present voltage and offers peak data hold function
- Very small probe-to-test surface distances, excellent spot resolution and accuracy
- · Chopper probe is DC stable with/without incident air ion flow

### **Applications**

Static charge measurement of semiconductor devices. Monitor electrostatic levels in IC production processes, semiconductor production processes and various production lines.

### **Specifications**

-	0 to ±1kV (Model 541A-2: 0 to ±100V)
Output Monitor	
Output Voltage	0 to ±10V (1/100)
Output Current	4 to 20mA
Probe-to-Surface Separation	Range of 1 to 10mm
Accuracy	±1% (Full Scale) or better
Speed of Response	50ms for 1kV step (10 to 90%)
Operating Conditions	
Temperature	15 to 35°C
Relative Humidity	5 to 85%RH, noncondensing
	Line to 15V DC adapter
	15.2cm W x 10.2cm H x 21.6cm D
Weight	770g
-	•



Probes for Model 541A...... Model 541PR-S (side view)

Model 541PR-E (end view)

Model 541P-S (side view)

Vacuum application probes also available

Walking Test Adapter ...... For analysis of charge levels on the human body

Compliant with ANSI/ESD STM97.2; IEC 61340-4-5



# Model 542A-1 AC Feedback Electrostatic Voltmeter - USB Supported

### **Features**

- USB or RS-232 serial port enables computer-based control & monitoring
- · Visual and audible alarms
- LCD screen displays present voltage and offers peak data hold function
- · Drift-free measurements
- Chopper probe is DC stable with/without incident air ion flow
- · Voltage output monitor for remote monitoring or control

### **Applications**

Static charge measurement of plastic and polymer film. Monitor electrostatic levels in LCD production processes and for various production lines.

### **Specifications**

 Measurement Range
 0 to ±10kV (Model 542A-2: 0 to ±20kV)

 Output Monitor
 0 to ±10V (1/1000); Model 542A-2: (1/2000)

 Output Current
 4 to 20mA

 Probe-to-Surface Separation
 Range of 15 to 30mm (Model 542A-2: 30 to 60mm)

 Accuracy
 ±5% (of Reading); ±0.2% (Full Scale)

 Speed of Response
 50ms for 1kV step (10 to 90%)

 Operating Conditions
 15 to 35°C

 Relative Humidity
 5 to 85%RH, noncondensing

 Power Supply
 Line to 15V DC adapter

 Dimensions
 15.2cm W x 10.2cm H x 21.6cm D

 Weight
 770g






# Model 541A, 542A Application Software

### **Explanation of the Screen**

1. Voltage display (V)	Display measured voltage
2. Positive (+) threshold (V)	Set the level
3. Negative (-) threshold (V)	Set the level
4. Positive (+) peak value (V)	Display maximum voltage value of positive (+) side
5. Negative (-) peak value (V)	Display maximum voltage value of negative (-) side
6. Menu screenDisplay the	screen setting of the measurement
7. Data save	Save measurement value
8. Reset	Reset the peak value
9. Exit	Terminate the software
10. Length of timeSelect	the length of time for displaying the measurement value (storage time)



To enhance the utility of Model 541A and Model 542A, Trek provides application software (available for download at www.trekinc.com) and a USB or RS-232 serial port on both models for interfacing with a Windows® PC.

Trek's software thereby enables touchscreen setting of threshold values and preservation of data. The data can be viewed graphically (screen shot above), in real time. Other PC-friendly adjustments include threshold setting, alarm ON/OFF, and storage time.

# Model 821HH Infinitron® Hand-Held Contacting Electrostatic Voltmeter

### **Features**

- Portable, battery-operated, compact design
- Trek contacting technology enables precise surface voltage measurements
- Measure conductive and insulative objects/surfaces with virtually zero charge transfer to the measurement probe
- · Save test data to internal memory
- Data graphing capabilities (via connection with PC)

### **Specifications**

Input Characteristics	Resistance >10 <sup>14</sup> , Capacitance <10 <sup>-14</sup> F
Measurement Range	0 to ±2kV DC or peak AC
	1kHz (-3dB)
Accuracy	±1% (Full Scale)
Operating Conditions	
	15 to 35°C
	5 to 75%RH, noncondensing
Power Supply	Internal NiMH battery (approx. 8 hours
	continuous usage from a full charge) or external
	15V @ 1A supply/charger for line operation
Dimensions	14.0cm W x 24.0cm H x 5.25cm D
Weight	1.13kg (includes battery)
-	<b>3</b> (



(CE compliant)\*


# Model 156A Charged Plate Monitor

### **Features**

- · Compliance to IEC 61340-5-1 and ANSI/ESD STM3.1
- · Mode of operation is easy to select via three-position toggle switch
- Standard ion collection plate, 6" x 6"

### **Specifications**

Measurement Range	.0 to ±1100V DC or peak AC
Small Signal Bandwidth	1kHz (-3dB)
Output Monitor	1/200 of the plate voltage
Accuracy	±0.1% (Full Scale)
Offset Voltage	±10mV
Output Noise	10mV rms
Operating Conditions	
Temperature	5 to 35°C
Relative Humidity	to 80%RH, noncondensing
Power SupplyBuilt-in recharge	
of continuous usage from a full charge) or b	y using a recharge/operating
AC adapter. AC power adapter fo	r all global areas is available.



Dimensions	31.8cm W x 8.3cm H x 28.0cm D
Weight	2.0kg




# Model 157 Charged Plate Monitor

### **Features**

- Compliance to IEC 61340-5-1 and ANSI/ESD STM3.1
- · Store & retrieve data as data points or graphs; internal memory
- · USB connection (to PC) enables real time data
- Connect to the optional Thermohygrometer Kit (Omega Model HH331)
- · Bar code wand also available

### **Specifications**

Measurement Range	0 to ±1020V DC or peak AC
Large Signal Bandwidth	80Hz (-3dB)
Monitor Output	1/200 of the plate voltage
Accuracy	±0.1% (Full Scale)
Offset Voltage	under ±10mV
Output Noise	10mV rms
Operating Conditions	
Temperature	5 to 35°C
Relative Humidity	to 80%RH, noncondensing
	t-in rechargeable battery (approx. 8 hours of
	ull charge) or by using a recharge/operating
AC adapter. AC po	wer adapter for all global areas is available.



Dimensions	25.4cm W x 10.2cm H x 24.1cm D
Weight	2.0ka



### Ion Collecting Plates (can be used with Model 156A and 157)

Standard Charged Plate, 15cm x 15cm (6" x 6") - Model 156AP-C150x150-R3M\*\*; Standard Charged Plate, 25mm x 25mm (1" x 1") - Model 156P-C25x25-S3M; High Temperature Charged Plate, 25mm x 25mm (1" x 1") - Model 156P-C25x25-S3M; High Temperature Charged Plate, 25mm x 25mm (1" x 1") - Model PD04002AP

\*\* Complies with IEC 61340 Standard Note: Other sizes and shapes of charge plates are available. Deionized water probes are also available (PM08035)



# Model 158A Charged Plate Monitor

Trek Model 158A Charged Plate Monitor is the premier instrument to evaluate the performance of air ionization systems. Its design includes a color graphics display for viewing of discharge waveforms and offset voltage in the time domain and the ability to store test data and waveforms for hundreds of ionizer tests. This unit employs Trek's patented voltage-follower technique to provide accuracy, stability and bandwidth well beyond the performance capabilities of field meter technology.

### **Features**

- · Compliance to IEC 61340-5-1 and ANSI/ESD STM3.1
- · User-friendly compact design
- · Superior data collection and storage capability
- · Large LCD color graphic display
- · Navigate via touch screen or function keys
- · Standard ion collecting plates available (see below)
- Operate in Float Mode, (+) Decay Mode, or (-) Decay Mode
- Programmable voltage balance and (+) and (-) discharge time
- Performs float voltage and discharge time EOS/ESD measurements
- · Allows multiple operational and programing options
- Can be pre-set to perform automated tests
- Can store/retrieve previously defined test parameters
- Test data can be saved for future reference/retrieval
- · Long battery life
- USB port enables data transfer
- · Optional barcode scanner with bluetooth technology



Please specify plate type(s) when ordering Model 158A. A Model 158A Charged Plate Monitor Kit is also available. See details below.

### **Specifications**

Measurement Range	0 to ±1100V DC or peak AC
	80Hz (-3dB)
	1/200 of the plate voltage
Accuracy	±0.1% (Full Scale)
Offset Voltage	±10mV
Output Noise	10mV rms <sup>2</sup>
Operating Conditions	
Temperature	5 to 35°C
	to 80%RH. non-condensing

Power SupplyBuilt-in rechargeable battery (approx. 6 hours of
continuous usage from a full charge); can also be
operated using the supplied AC adapter.
Dimensions
Weight2.2kg

### Ion Collecting Plates

Standard ion collecting plates are ordered separately; standard 6" x 6" plate and standard 1" x 1" plate are available. Refer to relevant photos on prior page.

### Model 158A Charged Plate Monitor Kit

This kit includes Model 158A charged plate monitor, standard 6" x 6" collecting plate, standard 1" x 1" collecting plate, charged plate handle, walking test adapter assembly, mini-tripod, and custom carrying case.

# Model 511/1501 ESD Audit Kit



Trek's Model 511/1501 ESD Audit Kit includes the Model 511 Ionizer Kit (electrostatic field meter, charger, and charge plate) and Model 1501 (surface resistance meter) in a compact carrying case. Please refer to specifications below. Most items can be ordered individually. Refer to details below.

The carrying case and all of its contents are shown (far left). The kit as packaged for delivery is also shown (near left). Orders in the USA include ground plug adaptor, AC receptacle tester, and 2.75W charger/USB adaptor. (below).



USA only

# Model 511 Electrostatic Field Meter

### **Features**

- · Switch selectable measurement range
- · Hand-held, portable, non-contacting
- · Chopper-stabilized technology
- · Reliable in ionized or non-ionized environments
- Complies with ANSI/ESD SP3.3

### **Specifications**



# Model 1501 Surface Resistance Meter


### **Features**

- · Auto-ranging
- · Lightweight, hand-held
- · Displayed values can be stored in internal memory
- · Records temperature and relative humidity
- · Built-in electrodes with conductive rubber
- Appropriate electrodes can be externally connected for tests (IEC 61340: -4-1, -2-3, -4-5; ANSI/ESD: S4.1-2006; ANSI/ESD STM: 11.11-2006, 11.12-2007, 11.13-2004, 12.1-2006, 97.1-2006)

### **Specifications**

Measuring Range
Display Range $\dots 1x10^z$ to $9x10^z$ where $z =$ measuring range exponent
Accuracy10% to 25% of reading (depends on measuring range)
Operating Conditions
Temperature5 to 40°C
Relative Humidityto 75%RH, non-condensing





Power Supply	Rechargeable lithium battery, 3.6V 900mAh
Dimensions	14.5cm H x 8.0cm W x 3.5cm D
Weight	290a

# Model 152-1 Surface Resistance / Volume Resistance Meter

### **Features**

- · Accuracy, stability and repeatability in a lightweight, portable design
- Complies with IEC 61340-5-1 for Surface Resistance Measurements
- Complies with IEC 61340-2-3 for Volume Resistance Measurements
- Technique used to measure surface resistance and volume resistance conforms to ANSI/ESD Association standards (STM2.1, 4.1, 7.1, 9.1, 11.11, 11.12, 12.1, 11.13, 97.1)
- Wide measurement ranges of 10<sup>3</sup> to 10<sup>13</sup>
- · Variety of probes available (see photo at right) Model 152P-CR-1 ...... Surface resistance/volume resistance (center top) Model 152P-2P.....Two-point surface resistance (center bottom) Model 152BP-5P.....Point-to-point surface resistance (lower right) Model 152AP-3mm x 25.4mm......Miniature resistance probe (pair)


Part CN 1K039......Walking test adapter kit (lower left)

### **Specifications**

Measurement Range
(using probe 152BP-5P, 152P-2P, or 152P-CR-1)
Test Voltage Select 10V or 100V (±2%) using the selection switch
Power SupplyTwo 9V alkaline batteries provide approx. 6 hours
of power for portable operation. AC line adapter
available for all global areas.



Operating Conditions	
Temperature	15 to 35°C
Relative Humidity	5 to 80%RH, noncondensing
Dimensions	10.0cm W x 18.0cm H x 4.4cm D
Weight	500g (includes battery)



# Model 901HS High-Sensitivity ESD Event Detector

### **Features**

- · Sensitive to ESD voltage levels as low as 10V at 50mm
- · Well-suited for Charge Device Model (CDM) and discharge between metallic electrodes
- · ESD event detection conveyed through visual and audible alert systems
- Good for difficult-to-reach locations (antenna-on-cable design)
- · Compact, lightweight design and highly accurate data
- Operates on four AA batteries; AC power adapter for continuous
- Alternate antenna for less sensitive detection (50V @ 90mm)

### **Specifications**

Indicators	Audible alarm and 5 color-coded LEDs to visually
	indicate intensity
Alarm	Automatic or manual reset control
Dimensions	8.0cm W x 11.0cm H x 4.5cm D
Weight	500g (includes battery)



(CE compliant)\*

www.trekinc.com

# Model 950 Nozzle Ionizer

The Model 950 is a nozzle type air ionizer which removes dust contamination and eliminates static electricity by use of high pressure ionized air flow. The compact nozzle body contains a built-in high-voltage power supply and an abnormal operation detection/warning output circuit. Model 950 is operated by connecting a compressed air supply and a 24V power supply to the unit.

Using a high-frequency corona discharge, Model 950 enables the efficient elimination of static electricity. Selection of specific nozzles (from a variety of options, as shown on p.7) to transfer ionized air provides utility for Model 950 in a wide range of applications. The Model 950 uses an LED display and contact output to indicate abnormal conditions. The high voltage supply and ionizing electrode can be replaced easily through the back of the unit. These features facilitate easy cleaning and maintenance at the production line site, thereby reducing downtime.

# Please specify nozzle type(s) when ordering Model 950

### **Features**

- · Ultra-small compact body
- High voltage failure and emitter needle contamination detector function
- · Outputs a relay signal when abnormal operating conditions occur
- Optional tubes allow transfer of ionized air to remote or difficult-to-reach locations
- Easy maintenance built-in power supply with a replaceable emitter unit makes for easy cleaning and replacement
- · Excellent ion balance
- A wide range of optional nozzles and tubes for various applications



LED Display (displays the information shown in the chart below)



THE FACE OF THE PARTY OF THE PA

Rear of the unit showing the discharge needle access and the connector for power input, output signal, and failure alarm output relay signal

### **Operating Conditions – LED Indicators**

. •				
Condition	"Power" Green LED	"H. V." Green LED	"C. C." Yellow LED	"Alarm" Red LED
Normal Operation	•	•		
H.V. Malfunction	•			•
Maintenance Needed (clean the needle)	•	•	•	
H.V. Output Off	•			
Power Off				

### **Specifications**

Discharge MethodHi	igh-frequency AC corona discharge method
Input Power Supply Voltage	24V DC±10%
Power	2.4VA
Air Purge-Operation Pressure	
Dimensions8.65	cm D x 1.8cm W x 5.0cm H (main unit only)
Weight	Approx. 80g (main unit only)
Operating Conditions	
Temperature	0 to 40°C
Relative Humidity	15 to 65%RH, noncondensing

Ozone Density 0.05ppm or less	s (at a distance of 300mm from air outlet)
Ion Balance	±15V or less (0.05 to 0.5MPa)
Material	Enclosure: ABS
	Cover: stainless steel
	Discharge needle: tungsten
Air Pining Dimension	6mm O D

(CE compliant)\*

### Model 950 Optional Parts (length, material type and part numbers as noted)



Seamless carrier pipe nozzle (950-C200 in photo)

100mm 950-C100 200mm 950-C200

300mm 950-C300 400mm 950-C400 500mm 950-C500



Shower nozzle 950-60S



100mm 950-100B 200mm 950-200B 300mm 950-300B



Flat nozzle 950-F

Carrier tube nozzle (950-TT in photo)

Teflon carrier tube nozzle 950-TT Silicon carrier tube nozzle 950-ST






AC Adapter (950-24VA in photo)
950-24VA AC Adapter
(power supply + signal cable + grounding wire)


950-24V AC Adapter (power supply only)

### Model 950 Other Optional Parts (part numbers as noted)

Bar nozzle L-type 950-100BL 950-200BL Pipe nozzle 950-120PSP Mounting Frame 950-FM

# Main Unit Dimensions Mounting Frame Dimensions Mounting Frame Dimensions






### Theory of Operation – DC Feedback Electrostatic Voltmeter

Trek offers two types of technology in the company's Electrostatic Voltmeters. One product line utilizes DC feedback technology while the other product line is based on Trek's novel approach to electrostatic measurement via patented AC feedback technology.


The DC Feedback Electrostatic Voltmeters use a well-known technology that Trek has employed for over 45 years (diagram below). The design utilizes a field-nulling method where the body of the probe is driven to the voltage being measured. This provides very high accuracy and fast speed of response. Since the probe is spaced relatively close to the surface being measured (1-2 mm typical) it is capable of measuring very small surface areas, with no arc over.



### Theory of Operation - AC Feedback Electrostatic Voltmeter

The AC Feedback Electrostatic Voltmeters are based on a unique design developed and patented by TREK, INC, to address some of the problems associated with electrostatic fieldmeter technology. The AC feedback technology (diagram at right) delivers accurate measurements over a wide range of probe-to-surface spacings without the need to generate high voltage. Compare this to fieldmeter technology which requires a specific fixed spacing in order to provide useful measurements. In addition, the AC feedback electrostatic voltmeter can measure smaller surface areas than fieldmeters because Trek's technology allows the probe to be placed closer to the surface.

For a complete technical description of the DC Feedback Technology and AC Feedback Technology please contact Trek.



11

### Notes

### Notes

### **Trek Sales & Service**

### Warranty

A ONE (1) YEAR Warranty applies to Trek's products. TREK, INC. agrees to correct, either by repair, or in the company's sole discretion, by replacement, any defect of material or workmanship which develops within one year from date of original purchase by the customer (user), provided that investigation and factory inspection by the company discloses that such defect developed under normal and proper use.

### Calibration & Repair

TREK, INC. provides calibration and repair services for all Trek products. We have Authorized Service Organizations located around the world. Please contact Trek's Customer Service Department for assistance or go to www.trekinc.com to locate a service facility.

### **Rental Service**

Trek's rental program provides cost-effective access to equipment for short-term projects or emergencies. For more information, please contact Trek's Sales Department.

### **Pricing & Specifications**

Product pricing and specifications are subject to change. Please contact Trek's Sales Department for the most up-todate information before placing an order.

### **Custom Solutions & OEM Applications**

Trek can provide custom solutions for applications needing more than an "off-the-shelf" product. Trek utilizes its decades of experience and technical expertise to design, develop and manufacture custom products which address the specific needs of an OEM application. Please contact Trek's Sales Department about custom design services

### **Demonstration Units**

Trek has a variety of demonstration instruments available to introduce products to customers interested in verifying operation for specific applications. To learn more about demo equipment please contact Trek's Sales Department.

### **For Assistance**

Sales Department: HV-Sales@aei.com
Customer Service Department: HV-Sales@aei.com

In early 2018 Advanced Energy Industries, Inc. acquired Trek. Later in 2018, AE acquired Monroe Electronics' Electrostatic & ESD product line and relocated production and sales to AE's Trek facilities in Lockport, NY.

www.trekinc.com

www.trekinc.com/monroe/

www.advancedenergy.com





### **EDACPOWER ELECTRONICS PTE LTD**

6 Tagore Drive, #01-02 Tagore Building, Singapore 787623 Tel: +65 6454 7877 | Fax: +65 6453 7977 Email: sales@edac.com.sq | Website: www.ep-power.com

Trek products generate high voltage. Please read the instruction manual and notes carefully before using the instruments.